

we
are
arco

we
make
tables

arco

product
Shift
Extendable

designer
Jorre van Ast


Year
2019

Assembly
instructions

Please follow step 1 - 11.



2




1. put all screws in place,
don't lock screws immediately!

2. tighten screw no.1


3. tighten screws no.2

4. screw tops have to be flat
with profile!

1



3




4


Pay attention to
wheel direction!

perpendicular to
table length


parrallel to
table length




5



6




7



8

slide the bushings
to the inner
table side


slide the spring
to the outer
table side



Make sure that spring and bushing
are in the correct position

Check

10




tighten (6x)

#5

9

Place extension leaf between the spring and bushing



11