

we
are
arco

we
make
tables

arco
VISION


product
Vision Modules

designer
**Pierre Mazairac &
Karel Boonzaaijer**

Year
1985


General
assembly
instructions

Please follow step 1 - 24



Note:


- only mount to a stone or concrete wall
- make sure the wall is straight




Frame is optional

- ① only mount to a stone or concrete wall
make sure the wall is straight


example module width 54 cm




- ② repeat drill template for modules with 54 cm and 72 cm partitions




③




④




5



6




7




8


Place module over wallbracket




⑨ Vertical adjustment




⑩ Depth adjustment




⑪ Anti-tilt lock



⑫ Cover cap




13 Door hinge adjustment




1. Vertical adjustment
2. Horizontal adjustment
3. Depth adjustment

14 Flap hinge adjustment




1. Vertical adjustment
2. Horizontal adjustment
3. Depth adjustment


15 Flap holder adjustment




16 Remove drawer




⑪ Horizontal drawer front adjustment




⑫ Forward drawer front adjustment




⑬ Vertical drawer front adjustment




⑭ Depth adjustment



21




22



23

Max 10 kg
18/27/36/54/72 cm wide module



24

Max 10 kg per partition
108/144/162/216/270 wide module

